Stock Farm Tractor Pull Rules

12500LBS

1. MUST BE FACTORY CAST CENTER WHEELS! NO PRESSED STEEL WHEELS!!!!!!!

- 2. Tractors must have all wheels and attached rear fenders.
- 3. Contest is open to all rubber-tired, farmer-owned tractors. (No industrial)
- 4. Tractors may enter in more than one class, with entry fee for each class, but only once in each class
- 5. Weight includes driver. No weight changes. All weights must be securely fastened to the tractor chassis. Front weights must not extend beyond 24 inches of the tractor. Loss of weight will disqualify entry.
- 6. Stationary hook point height is a maximum of 20 inches from the ground to the top of hitch point with hitches no closer then 18 inches to center of the rear axle. No drawbar will be allowed to be raised after the pull has started.
- 7. Bring own 3" clevis. Pulling eyes will be permitted. Must be bolted with a 1 inch bolt or drawbar pin. Sled hook must hook in and out freely.
- 8. No dual wheels, tire chains or sharpened tires are not permitted.
- 9. Maximum RPM 3000
- 10. Each tractor pull will end when the tractor spins out, powers out, stops or is stopped by judges. Anyone who fails to stop when judge red flags them will be disqualified.
- 11. Drivers must be 18 years of age or older.
- 12. Contestants will have one chance to change gears within the first 100ft.
- 13. The tractor driver must remain seated at all times during the pull and must have one hand on the steering wheel.
- 14. Tractors may be checked after their pull if there is any question or rule violation.
- 15. Any persons under the influence of alcohol or operating a tractor in an unsafe manner will be disqualified.
- 16. All tractors must have factory starters, PTOs hydraulics, factory manifold, and turbo
- 17. All engines must appear visibly stock to the year make and model
- 18. Straight exhaust on turbo tractors. Exhaust must exit upwards
- 19. Only one turbo for stock farm classes.
- 20. All decisions of the Rules Committee are final

Hot Farm

12500LBS

ALL RULES FROM STOCK TRACTOR CLASS APPLY TO HOT FARM EXCEPT:

- 1. PTO, HYDRAULICS NOT REQUIRED
- 2. CUT TIRES PERMITTED
- 3. AUXILIARY FUEL PUMP PERMITTED
- 4. KILL SWITCH AND SCATTER BLANKET REQUIRED
- 5. WATER INJECTION PERMITTED
- 6. 3"X3" TURBO MAX, NO BUSHINGS
- 7. STEEL PRESS WHEELS PERMITTED